



INSTALLATION TIPS

1. Only use a professional installer to lay your natural floorcovering. The material can be more difficult to seam and cut than the common carpet.
2. The product needs to be glued down (not stretched in) and finished at the walls and doorways with quarter round, shoe molding, and threshold stripping.
3. It is very important to let the product acclimate to the temperature in the room that it is being installed. It is recommended to let it sit for 48 hours before installing. This is especially appropriate in areas of the country with extreme temperature changes.
4. Always seam seagrass with the grain. Seam the same direction that it comes off of the roll. The roll is roughly 13 feet wide.
5. If installing on stairs, install the seagrass with the direction it comes off the roll going up the stairs. By the grain running up the stairs, it will decrease wear on the seagrass.
6. Do not install over any type of dampness or area that could have moisture in it. This includes any outdoor area that is uncovered or covered, such as screened in porches. This will cause problems such as mildew and dry rotting.